

## Installation Instructions Putty Pads for Electrical Outlet Boxes

1. Consult the appropriate UL listing for application criteria.
2. Remove any water, excess dust, dirt and oil from the application.
3. Remove the plastic liner from one side of the putty pad.  
(See Illustration # 1)
4. Line the pad up with one side of the box and fold over onto all surfaces of the electrical box (top, bottom, and sides) ensuring that the penetration is overlapped with the pad.  
(See Illustration # 2)
5. Overlap the box edges with the pad. When the wallboard is installed against the outlet box a tight seal will be created.
6. Remove the remaining plastic liner and work the putty into a smooth even thickness.
7. Make sure the entire surface is covered. To ensure a proper fit around the conduit and cables, cut slits in the pad where appropriate.  
(See Illustration # 3)
8. Trim excess at the corners and apply to conduit fittings.
9. To seal the conduits where they enter the outlet box, work the putty into a ball to securely cover area.  
(See Illustration # 4)
10. If putty pads have become wet before being installed, they should be discarded.

Illustration # 1



Illustration # 2




Illustration # 3



Illustration # 4

